

Framery One Compact | Touchscreen Instructions

ADJUSTING LIGHTING


ADJUSTING AIRFLOW

OCCUPANCY LIGHTS


BOOKING & ADJUSTING RESERVATIONS

POD RESERVATION STATUS

ADJUSTING LIGHTING




1 DEFAULT LIGHTING The pod automatically suggests video-optimized lighting when you step inside.




2 ADJUSTING THE LIGHTING Tap the Lights button on the main view.

Tap the arrow in the top left corner to return to the main view



3 TWO MODES Choose from Standard mode or Video call mode.




4 CUSTOM LIGHTING Adjust the intensity of the ceiling light & front light by moving the corresponding sliders up or down.

LIGHTING MODES

VIDEO CALL MODE Preset blend of ceiling light and front light adjusted to levels optimized to illuminate the user's face evenly during video calls

STANDARD MODE Top-down lighting from the ceiling light adjusted to enhance focus work

ADJUSTING AIRFLOW



1 ADJUSTING THE AIRFLOW Tap the Airflow button on the main view.

Tap the arrow in the top left corner to return to the main view



2 AIRFLOW INTENSITY Adjust the intensity of the airflow by moving the slider up or down.

Automatic mode will become available during 2024.

OCCUPANCY LIGHTS

GREEN LIGHT indicates the pod is available and free to use

YELLOW LIGHT indicates a meeting is starting in less than 5 minutes - or that a meeting has already started but no one has arrived yet

Pods must be connected to the calendar to enable yellow light functionality

RED LIGHT indicates the pod is currently occupied or in "Be right back" mode waiting for someone to return

framery

